



CARE AND MAINTENANCE

The Premium Series USB Charger are products of superior design and craftsmanship and should be treated with care. The following information will help you to protect your warranty coverage.

- The product is specifically manufactured to be used and stored at room temperature. (-5°C to +40°C, not exceeding an average of more than 25°C in any 24 hours period)
- Keep the device dry.
- Do not store the product in dirty, dusty areas.
- Do not expose the product to rough handling.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the product.

ADDITIONAL INSTRUCTIONS - PREMIUM USB CHARGER

- USB Charger is designed to work with most devices that have charger connectors and do not require software or proprietary USB signalling for charging.
- Disengage the charger from the track when not in use. Do not leave a fully charged battery connected to a powered charger as overcharging may shorten its lifetime.
- * *USB connector cable is not included.*

TECHNICAL SPECIFICATIONS

USB3 Premium Dual-Port USB Charger		
Electrical	Input Voltage	AC100 - 250V ~
	Output Voltage	DC5.0V
	Rated Current	3400mA max.
	Frequency	50Hz / 60Hz
Size and Weight	Diameter x Depth	67mm x 50.4mm
	Weight	Est. 90grams
Environmental	For indoor use only	
Function	USB Charger is designed to work with most devices that have USB charger connectors and do not require software or proprietary USB signalling for charging.	

Warranty 1 year subject to Eubiq Limited Warranty Statement

DMK-006-030-02-ENG



IMPORTANT SAFETY INFORMATION

- This user guide contains important product operating instructions, safety and maintenance information.
- Please read the user guide fully before use.



Do not slide along track.



Keep away from fire.




Keep away from water.




Not for outdoor use.



1 Align Locator to V-Groove.
Push charger to engage.
To "ON", turn charger 90° clockwise until a "click" sound is heard.



2 Charger is now in "ON" position.
(Blue LED indicator will illuminate)
To begin charging, connect the USB cable (not included) to your mobile device. **Reverse the steps to disengage.**



1.0A



2.4A

CHARGING INFORMATION

- 2 USB ports may be used to charge 2 smart devices concurrently.
- USB port marked **1.0A** should be used to charge smart mobile devices with max. input current of 1.0A.
- USB port marked **2.4A** should be used to charge smart devices and tablets with max. input current of 2.4A.